


Setting Energy Saving Mode


The RISO Digital Duplicator is equipped with an Auto-Power OFF function as the Energy Saving Mode. In order to save energy, please set the Auto-Power OFF function in accordance with the following procedure.

RISO CV series

- 1 Press the [CUSTOM] key.



- 2 Enter "15" using the Numeric Keys.




- 3 Press the [START] key.




- 4 Enter "2" using the Numeric Keys.
- 5 Press the [START] key.
- 6 Enter "16" using the Numeric Keys.
- 7 Press the [START] key.
- 8 Enter "3" using the Numeric Keys.
- 9 Press the [START] key.
- 10 Press the [CUSTOM] key.

RISO EZ3/2 series

- 1 Press the [CUSTOM] key.



- 2 Enter "10" using the Print Quantity keys.
- 3 Press the "+" key.




- 4 Enter "2" using the Print Quantity keys.
- 5 Press the [START] key.




- 6 Press the [CUSTOM] key.
- 7 Enter "11" using the Print Quantity keys.
- 8 Press the "+" key.
- 9 Enter "3" using the Print Quantity keys.
- 10 Press the [START] key.

RISO ME/MZ series, SE/RZ10 series, EZ5 series


1 Touch [Admin.] on the basic screen of any mode.




2 Touch [OK].




3 Touch [System] from the Display Access Buttons.




4 Touch [▶] to display [Energy Saving Mode] on the screen.





5 Touch [Energy Saving Mode].




6 Touch [Auto Power-OFF].



7 Enter "60" using the Print Quantity Keys to set the Waiting Time to "60" mn.



8 Touch [OK].



9 Touch [▶].

